Tyvek studies at BUW

Alex Kääpä, Sven Querchfeld, J. Rautenberg K.-H. Becker, K.-H. Kampert

Tyvek studies at BUW J. Rautenberg, BU Wuppertal

LTP 09.05.2019



BERGISCHE UNIVERSITÄT WUPPERTAL

- Aging of tyvek
- Step in aging due to freezing
- Absolute wave-length dependend reflectivity
- Diffuse vs. speciular reflectivity
- Reflectivity in Water

- Additional measurements by Sven
- Tyvek sample from the field, and unsued sample





Tyvek studies at BUW J. Rautenberg, BU Wuppertal

LTP 09.05.2019

Documentation:

• Bac. Thesis of Alex Kääpä, not as gap, only thesis:

https://astro.uni-wuppertal.de/fileadmin/physik/astro/mainpage/publications/theses/Bachelor/Kaeaepae-BSc.pdf

- Presentations at collab meetings:
 - Nov. 2013 https://indico.nucleares.unam.mx/event/782/session/10/contribution/118

LTP 09.05.2019





SEM scan of samples (as in GAP-2004-056 for damaged Tyvek):

- no obvious difference between new and used Tyvek samples
 - no cuts or broken/damaged stings
- no contamination of used probe

T) J.

 \rightarrow lower reflectivity just caused by smaller density?

Specular Reflectivity Measurement

• Experimental setup



- reflection probe: 6 fibers from 400 $\rm nm$ LED to sample, one fiber (Ø400 μm) back to photodiode
- signal of used (Old) and unused (New) Tyvek measured in air and deionized water (sample size $\sim 5\,{\rm cm}\times 5\,{\rm cm})$

Tyvek st J. Raute

• averaged over 30 positions to account for inhomogeneity

Since "recovery" after water refill observed in the pampa, measurement vs. time in water

- Indication of decrease with time in water
- To test bubble-hypothesis: use ultrasonic bath, but seems to destroy the tyvek structure



Specular Reflectivity Measurement

Tyvek New (Black) and Old (Red) Graph



- time depended measurement (1, 5 and 9 days after immersion)
- further decrease of reflectivity in water
- saturation for both samples after several days (caused by nano bubbles?)
- deviation for new sample drops significantly

Diffuse reflectivity measurments

- measurement of diffuse reflectivity in air and water with small integrating sphere
- air: consistenly lower reflectivity for used sample
- water: diffuse reflectivity measured with 405 nm laser diode used Tyvek ~3% lower than new sample (~same as for specular meas.)



Additional diffuse measurement

spectrometer measurement for new and old Tyvek and two samples after used in water (but already dried for several days)

shape changes slightly after used in water (see also page 9)



Tyvek studies at BUW J. Rautenberg, BU Wuppertal

LTP 09.05.2019



BERGISCHE UNIVERSITÄT WUPPERTAL



- two Tyvek samples from the same roll; one frozen in water and one in air down to the same temperature
- reheated samples measured in air
- no significant difference in reflectivity measured; the changes are well within margin of error

Tyvek studies at BUW J. Rautenberg, BU Wuppertal

LTP 09.05.2019

