AugerPrime SDEU ORR - SPMT

Antonella Castellina INFN and INAF - Torino



AugerPrime electronics Operation Readiness Review, November 10, 2024

Questions from the panel

- 7. Items considered not finished
- 2. Monitoring and Alarms
- 4. Transferring the databases for the SPMT and SF access by the collaboration.

The storage of the database-dumps at Lyon could serve as alternative.

- 8. Additional suggestions
- 2. Redundant oscilloscope for the SPMT setup

- 4. Transferring the databases for the SPMT and SPMT-HV tests to Malargue for secure storage and unified

7.2 — Monitoring of SPMT-related slow-control quantities

Target: daily detection of SPMTs turned off or malfunctioning Strategy: study Vmon (VoltagePM4), Imon (CurrentPM4) and their ratio R from the MonitUUB table

- ✓ Checks finalized and presented at the 15/10/2024 MOLTP meeting (download)
- \checkmark Automatized job runs every Monday using the previous week of monitoring data.



VERY limited man-power :

small % of Gialex time (not an Auger member anymore), everything ready to be implemented

Some help from Isabelle and Julian needed for:

- transferring of plot with daily histograms to the SD-shift website
- notification to the SD-shifters of the SPMTs showing an issue
- Update of the monitoring website to visualize the ratio R in the MonitUUB table.

Link to "draft" website

Merging request

7.2 — Monitoring of small showers and SPMT calibration

Monitoring of small showers acquisition

- Automatic job for the calculation of 1h averages of selected quantities run daily
- Results stored in the MonitSmallShowers
- tableVisualization in the monitoring website implemented, pending <u>merge request</u>





phpMyAdmin

🔂 Server: paomondb 🕨 📠 Database: AugerMonitor 🕨

Table: MonitSmallShowers "Table filled with spmt_ data averaged over 1 hour."

Browse		SQL	Search	≩ ∎insert	Export
	% Operations	Empty	Drop	_	

	Field	Туре	Collation	Attribute
nitor (72)	<u>Time</u>	datetime		
efinitionTab	GPSsec	int(10)		UNSIGNED
mitTab ab	Lsid	smallint(5)		UNSIGNED
ew	Events	smallint(5)		UNSIGNED
lts	EventsLPMT1	smallint(5)		UNSIGNED
iod iodDetails	ChargeLPMT1overChargeSPMT	float(6,2)		
iodItems iodReview	PeakLPMT1overPeakSPMT	float(6,2)		
ifos	SignalLPMT1overChargeSPMT	float(6,3)		
B IowUpNu	AreaOverPeakLPMT1	float(6,3)		
Period PeriodDetails	EventsLPMT2	smallint(5)		UNSIGNED
PeriodItems	ChargeLPMT2overChargeSPMT	float(6,2)		
PeriodReview SVeto	PeakLPMT2overPeakSPMT	float(6,2)		
SVetoType nStatus	SignalLPMT2overChargeSPMT	float(6,3)		
talTab age	AreaOverPeakLPMT2	float(6,3)		
entTab	EventsLPMT3	smallint(5)		UNSIGNED
entView InTab	ChargeLPMT3overChargeSPMT	float(6,2)		
EA	PeakLPMT3overPeakSPMT	float(6,2)		
rmMonitCalib ngIndicators	SignalLPMT3overChargeSPMT	float(6,3)		
s oyment	AreaOverPeakLPMT3	float(6,3)		
alib	EventsLPMTsAvg	smallint(5)		UNSIGNED
nallShowers JB	AreaOverPeakSPMT	float(6,3)		
JD mEroozo	AreaOverDeakSSDHG	float(6.3)		

Monitoring of SPMT inter-calibration

• Calculation of dynamic range extension and SPMT signal dispersion (manually) performed







Daily and separately for each tank with a SPMT

(1)		entries < 24 in the <i>MonitSmallShowers</i> t
(2)	Entries == 24	if Events<150 or Events>500 for ≥12 consecutive hour
(3)	Events∈(150-500)	<pre>if MaskedStatusLPMTx != 1 during the hours period</pre>
(4)		if CustomVEMChargeLPMTxFailures > ≥12 consecutive hours
(5)	MaskedStatusLPMT=1	if EventsLPMTx<30 or EventsLPMTx> ≥12 consecutive hours
(6)		if SignalLPMTxOverChargeSPMT<0.5 for ≥12 consecutive hours

(1)	if eta < 0.5 or eta > 2.5	ALARM1	failure
(2)	if S _{max} < 15 kVEM or S _{max} > 35 kVEM	ALARM2	too lov
(3)	if $\sigma[(S_{SPMT}-S_{LPMTs})/S_{LPMTs}]>0.2$	ALARM3	excessi in the i

For the small showers acquisition

table	ALARM1	since the quantities are hourly averages, there should be 24 entries per day per tank
	ALARM2	~200 events per hour expected for a tank with 3 working LPMTs, ~400 with only 1 working LPMT)
24	ALARM3	LPMTx is "unstable"
• 0.8 for	ALARM4	> 80% of failed calibrations using the custom algorithm
• 50 for	ALARM5	too many/too few events in the inter-calibration region
or >2.5	ALARM6	raw approximation for the inter-calibration factor, expected to be in the range (0.5, 2.5)

For the SPMT inter-calibration

es in the procedure and too low/high values of the inter-calibration factor

w/high values of the daily dynamic range extension

sive values of the daily **SPMT signal dispersion w.r.t. the LPMT signals** calculated inter-calibration region, which is related to the SPMT signal accuracy



7.4 – Transferring the databases

- The database with the results of the calibration of the SPMT are taken care of by the Napoli group. Currently the data are stored in MySQL (database and ascii files)
- The database with the results of the tests of the HVPS for the SPMT are stored in Pandora (<u>https://pandora.infn.it/public/b4022a</u>).
- The transfer will be organized by Napoli (SPMT) and Torino (SPMT-HVPS) in agreement with the local staff
- Note that any storage in Lyon will have to be transferred to the new data center in Bologna (in 2025)

8.2 – Redundant oscilloscope

- We acknowledge the need for redundancy
- A new oscilloscope can be provided in 2025
- If needed, an old one can be sent from Torino

